

## Calculite

### Standard Finish & Flange Options

#### Standard Finish Options

**Note:** Not all finishes available for all trims.



##### CL Clear

Clear is the most specular and therefore most efficient finish available. Clear reflectors deliver maximum photometric performance but can produce a mirror image of the interior of the space.



##### CCL Comfort Clear™

Comfort Clear is a slightly diffuse clear finish, which eliminates iridescence and reduces the mirror image inherent with specular finishes.



##### CCD Comfort Clear™ Diffuse

Comfort Clear Diffuse is a semi-specular finish that softens the light at the source of the reflector. The finish creates a subtle, even luminance from the reflector cone.



##### WH White

The matte white finish produces the brightest aperture when illuminated but provides the smoothest transition to most ceilings when off. White is available only with a white flange.



##### CCZ Champagne Bronze

Champagne Bronze is a semi-specular finish that softens the light at the source of the reflector while providing a warmer reflector appearance. Light output is slightly warmer as well.



##### GD Gold

Gold is a specular finish that provides a pale tint of color for slightly warming the light output. Reflector appearance mixes well in spaces with gold and brass finishes.



##### MG

Multigroove trims provide a seamless matte black aluminum baffling that captures stray light for a very low brightness aperture.



##### BK Black

Black is a specular finish that provides the lowest aperture brightness possible and significantly reduces source identification in a ceiling.

#### Flange Options



##### P Polished Flange

5/8" wide integral flange polished and finished to match the appearance of the interior of the reflector (available option on most reflector types).



##### W White Painted Flange

5/8" wide integral flange painted matte white. Standard trim detail on all reflectors.

#### Care & Maintenance

If handling of reflectors with Alzak® finish is required, the use of clean white or plastic film gloves is recommended to avoid fingerprints. Alzak® surfaces can be cleaned by the following methods: Wipe off with soft clean, dry lint-free cloth; or wipe off with a soft cloth dampened in mild detergent solution, rinse, then wipe dry with lint-free cloth or paper towel. Avoid gritty cleaning agents.

**Note:** Not all finishes are available for all trims. Refer to specification sheet for availability.

© 2008 Philips Group